

Candidate's Name: .....

Signature:.....

Random No.						Personal No.		

(Do not write your School Name or Number anywhere on this booklet.)

545/3  
CHEMISTRY  
(PRACTICAL)  
Paper 3  
Jul./Aug. 2023  
2 hours



**WAKISO-KAMPALA TEACHERS' ASSOCIATION (WAKATA)**

**WAKATA MOCK EXAMINATIONS 2023**

**Uganda Certificate of Education**

**CHEMISTRY**

**Paper 3**

**2 hours**

**INSTRUCTIONS TO CANDIDATES:**

*Answer both questions. Answers are to be written in the spaces provided in this booklet.*


*All your work must be in blue ink or black ink. Any work done in pencil will not be marked except drawings.*

*You are not allowed to use any reference books. (i.e. text books, booklets on qualitative analysis etc.).*

**All working must be clearly shown.**

*Mathematical tables and silent non – programmable calculators may be used.*

For Examiners' Use Only		
Q. 1		
Q. 2		
Total		



©2023 Wakiso Kampala Teachers' Association (WAKATA)

**Turn Over**

1. You are provided with the following:

**BA1**, which is a 0.5M solution of an acid.

**BA2**, which is a 1.0M solution of an alkaline compound.

You are required to determine the concentration of hydrogen ion,  $H^+$  in **BA1**.

**Procedure**

- Wrap a 250cm<sup>3</sup> plastic beaker with an aluminum foil properly to ensure good insulation.
- Use a burette to transfer 40.00cm<sup>3</sup> of **BA1** into the insulated plastic beaker. Measure the temperature of **BA1** and record the value in table 1.
- Use a measuring cylinder to transfer 10cm<sup>3</sup> of **BA2** into the insulated plastic beaker. Use the thermometer to stir the mixture and measure the temperature throughout the reaction. Record the highest temperature reached in table 1.
- Empty the insulated plastic beaker and rinse it with water.
- Repeat procedure (a) to (d) but with different volumes of **BA1** and **BA2** as given in the table 1 and complete the table.

**Table 1**


Experiment Number	1	2	3	4	5	6	7
Volume of <b>BA1</b> (cm <sup>3</sup> )	40.00	35.00	30.00	25.00	20.00	15.00	10.00
Volume of <b>BA2</b> (cm <sup>3</sup> )	10	15	20	25	30	35	40
Initial temperature of <b>BA1</b> (°C)							
Maximum temperature of mixture (°C)							
Temperature increase (°C)							

(08 marks)



**Questions.**

- (a) Plot a graph of temperature increase against volume of **BA2**. Use these points to draw and extrapolate two intersecting straight lines of best fit (05 marks)





(b) From your graph, read and record the volume of **BA2** where the two lines intersect. (01 mark)

(c) Calculate the volume of **BA1** required to neutralize the volume of **BA2** in (a) above. (02 marks)

(d) Write the equation of reaction between **BA1** and **BA2**. (1½ marks)

(e) Calculate the number of moles of;  
(i)  $\text{OH}^-$  in **BA2** that reacted. (02 marks)

(ii)  $\text{H}^+$  in **BA1** that reacted. (02 marks)

(f) (i) Determine the concentration of hydrogen ions,  $\text{H}^+$  in **BA1**. (02 marks)

(ii) Suggest the identity of the strong acid in **BA1** and explain your answer. (1½ marks)

2. You are provided with substance **F**, which contains **two** cations and **two** anions. Carry out the following tests in table 2 to identify the cations and the anion in **F**. Identify any gas(es) evolved.

Record your observations and deductions in the table 2.

(25 marks)

Table 2

TESTS	OBSERVATIONS	DEDUCTIONS
(a) Heat a spatula end-ful of <b>F</b> strongly in a dry test tube.		
(b) To two spatula end-fuls of <b>F</b> , add distilled water drop wise and stir until <b>F</b> dissolves.  Filter and keep both the filtrate and residue.		
(c) Divide the filtrate into three parts of about $2\text{cm}^3$ each.  (i) To the first part of the filtrate, add dilute sodium hydroxide solution drop-wise until in excess.		
(ii) To the second part of the filtrate, add dilute ammonia solution drop-wise until in excess.		

TESTS	OBSERVATIONS	DEDUCTIONS
(iii) To the <b>third</b> part of the filtrate, add 4–5 drops of dilute nitric acid followed by 3–4 drops of silver nitrate solution.		
(d) Put all the residue into a clean test-tube and dissolve it in dilute nitric acid. Divide the resultant solution into two parts and test as follows:  (i) To the <b>first</b> part, add dilute sodium hydroxide solution drop-wise until in excess.		
(ii) To the <b>second</b> part, add dilute ammonia solution drop-wise until in excess.		

(e) (i) The cations in **F** are.....and.....

(ii) The anion in **F** is .....

END