


MOMENTS.

EXPERIMENT TO VERIFY THE LAW OF MOMENTS.



- ✓ The meter rule is balanced on the knife edge at its midpoint.
- ✓ masses M_1 and M_2 are suspended such that M_1 is on one side of the fulcrum and M_2 on the other side.
- ✓ The positions of M_1 and M_2 are adjusted till the ruler is in equilibrium in a horizontal position.
- ✓ The distances d_1 (from M_1 to fulcrum) and d_2 (from M_2 to fulcrum) are read and recorded.
- ✓ The experiment is repeated using different sets of masses.
- ✓ The results are tabulated in a suitable table including values of $M_1 d_1$ and $M_2 d_2$.
- ✓ It is observed that $M_1 d_1 = M_2 d_2$. Hence verifying the law of moments.


Table.

$M_1(g)$	$M_2(g)$	$d_1(cm)$	$d_2(cm)$	$M_1 d_1 (gcm)$	$M_2 d_2 (gcm)$
50	100				
100	200				
150	300				
200	400				
250	500				

By N. Merand 0745644028/0779990583

MOMENTS.

Determining Mass of the metre rule using standard mass.



- ✓ The metre rule is balanced on the knife edge and the centimeter mark is recorded at the balance. (This is the centre of gravity)
- ✓ A known mass M_s is suspended near one end of the meter rule.
- ✓ The meter rule is adjusted until it balances horizontally.
- ✓ The distances d_1 and d_2 from the pivot are to the mass and to the centre of gravity mark respectively are recorded.
- ✓ The experiment is repeated for other values of M_s .
- ✓ The results are tabulated including values of $M_s d_1$.
- ✓ A graph of $M_s d_1$ against d_2 is plotted.
- ✓ The slope is determined
Slope, $s = \frac{\Delta M_s d_1}{\Delta d_2} = \text{mass of the metre rule}$.


$s = \text{mass of the ruler}$.

Table of results.

$M_s(g)$	$d_1(cm)$	$d_2(cm)$	$M_s d_1$
100			
200			
300			
400			
500			

MOMENTS.

Determining the unknown mass using a metre rule and a standard mass.



- ✓ The metre rule is balanced horizontally on the knife edge.
- ✓ Masses M and M_1 are suspended on the sides of the metre rule with the pivot in the middle.
- ✓ The distances are adjusted for the system to balance again.
- ✓ The distances d and d_1 are measured and recorded from the pivot to the unknown mass M and M_1 respectively.
- ✓ The results are tabulated including values of $M_1 d_1$.
- ✓ A graph of $M_1 d_1$ against d is plotted.
- ✓ The slope is determined.

$$\text{slope } s = \frac{\Delta M_1 d_1}{\Delta d}$$

Thus the slope is the mass of required graph.





Table of results.

M_1, d_1

M_1 (g)	d_1 (cm)	d (cm)	$M_1 d_1$ (gcm)
100			
200			
300			
400			
500			

DETERMINING "g" ACCELERATION DUE TO GRAVITY.



Formula $g = \frac{4\pi^2}{\text{slope}}$

Procedures:

- ✓ The length l of the pendulum bob is measured and recorded.
- ✓ The pendulum bob is displaced through a small angle and allowed to oscillate.
- ✓ The time t , for 20 oscillations is noted.
- ✓ The experiment is repeated for different increasing values of l .
- ✓ The results are tabulated including the values of T and T^2 .
- ✓ A graph of T^2 against l is plotted.
- ✓ The slope is calculated.

The acceleration due to gravity $g = \frac{4\pi^2}{s}$

Table of results.

l (cm)	t (s)	T (s)	T^2 (s ²)

Note:

$$T = \frac{t}{20}$$

By N. Merand 0745644028
0779990583.